

KV-C2553E/C2953E

RM-816

SERVICE MANUAL


Spanish Model

KV-C2553E

Chassis No. SCC-E22E-A

KV-C2953E

Chassis No. SCC-E22H-A



AE-1C CHASSIS

MODELS OF THE SAME SERIES

KV-C2553E/C2953E

KV-A2113E/A2513E

KV-E2523E/E2923E

SPECIFICATIONS

【KV-C2553E/C2953E】

Television system

B/G/H

Color system

PAL, SECAM, NTSC3.58, NTSC4.43

Stereo system

GERMAN /NICAM stereo

Channel coverage

VHF: E2-E12 UHF: E21-E69

CABLE TV (1) : S1-S41

CABLE TV (2) : S01-S05, M1-M10, U1-U10

Picture tube

Black Trinitron tube

Approx. 63.5 cm (25 inches)

(Approx. 59 cm picture measured diagonally)

110° -degree deflection

Approx. 72.4 cm (29 inches)

(Approx. 68 cm picture measured diagonally)

110° -degree deflection

Inputs

1 21-pin connector:

CENELEC standard including RGB input.

2 21-pin connector:

including S video input

Flont : Audio and video input jacks:

phono jack.

Including S Video input

Y: 1Vp-p±3dB 75ohm

C: 0.3Vp-p±3dB 75ohm

Outputs

21-pin connector: CENELEC standard

Headphones jack: stereo minijack

External speaker terminals: 2-pin DIN

Audio output jacks: phono jack (output dependent upon TV settings)

30 W + 30 W

97Wh (KV-C2553E)

107Wh (KV-C2953E)

Approx. 769×495×478 mm (w/h/d) (KV-C2553E)

Approx. 854×555×510 mm (w/h/d) (KV-C2953E)

Approx. 38kg (KV-C2553E)

Approx. 52kg (KV-C2953E)

-Continued on next page-



MICROFILM

TRINITRON® COLOR TV

SONY®

[RM-816]

Remote control system
Power requirements

infrared control
3V dc
2 batteries IEC designation
R6 (size AA)

Dimensions

Approx. 75×221×23mm(w/h/d)

Weight

Approx. 230g (including batters)

Accessories supplied



IEC designation R6 batteries (2)

Supplied accessories

RM-816 Remote Commander (1)
IEC designation R6 batteries (2)

Design and specifications are subject to change without notice.

21 pin connector (① 1, ② 2)



Pin No	1	2	Signal	Signal level
1	○	○	Audio output B (right)	Standard level: 0.5Vrms Output impedance: Less than 1kohm*
2	○	○	Audio input B (right)	Standard level: 0.5Vrms Input impedance: More than 10kohms*
3	○	○	Audio output A (left)	Standard level: 0.5Vrms Output impedance: Less than 1kohm*
4	○	○	Ground (audio)	
5	○	○	Ground (blue)	
6	○	○	Audio input A (left)	Standard level: 0.5Vrms Input impedance: More than 10kohms*
7	○	●	Blue input	0.7V±3dB, 75ohms, positive
8	○	○	Function select (AV control)	High state (9.5-12 V): Part mode Low state (0-2 V): TV mode Input impedance: More than 10kohms Input capacitance: Less than 2 nF
9	○	○	Ground (green)	
10	○	○	Open	
11	○	●	Green	Green signal: 0.7V±3dB, 75ohms, positive
12	○	○	Open	
13	○	○	Ground (red)	
14	○	○	Ground (blanking)	
15	○	-	Red input	0.7V±3dB, 75ohms, positive
	-	○	(S signal) chroma input	0.3V±3dB, 75ohms, positive
16	○	●	Blanking input (Ys signal)	High state (1-3 V) Low state (0-0.4 V) Input impedance: 75ohms
17	○	○	Ground (video output)	
18	○	○	Ground (video input)	
19	○	○	Video output	1V±3dB, 75ohms, positive Sync: 0.3V (-3, +10dB)
20	○	-	Video input	1 V±3dB, 75ohms, positive Sync: 0.3V (-3, +10dB)
	-	○	Video input/Y (S signal)	1 V±3dB, 75ohms, positive Sync: 0.3V (-3, +10dB)
21	○	○	Common ground (plug, shield)	

○ connected ● unconnected (open)

* at 20 Hz-20 kHz


4 pin connector (⑤)

Pin No	Signal	Signal level
1	Ground	
2	Ground	
3	Y (S signal) input	1V±3dB 75ohm, positive Sync 0.3V ⁻³ / ₊₁₀ dB
4	C (S signal) input	0.3V± 3dB 75ohm positive

TABLE OF CONTENTS

<u>Section</u>	<u>Title</u>	<u>Page</u>	<u>Section</u>	<u>Title</u>	<u>Page</u>
1. GENERAL			4. CIRCUIT ADJUSTMENTS		
	How to Receive NICAM TV Programmes.....	4	4-1.	A Board Adjustments.....	19
	Turning the TV Unit ON and OFF.....	5	4-2.	A1 Board Adjustment.....	19
	TV Channel Presetting.....	5	4-3.	B1 Board Adjustments.....	20
	Basic Functions.....	7	4-4.	D Board Adjustments.....	21
	Special Functions.....	8	4-5.	J1 Board Adjustments.....	21
	Use of the Teletext Service.....	8	4-6.	V Board Adjustment.....	22
	Connections and Optional Functions.....	10	4-7.	Secondary Adjustments.....	22
	General Information.....	11			
2. DISASSEMBLY			5. DIAGRAMS		
			5-1.	Block Diagram.....	23
2-1.	Rear Cover Removal.....	12	5-2.	Circuit Boards Location.....	29
2-2.	Chassis Assembly Removal.....	12	5-3.	Schematic Diagrams and Printed Wiring Boards.....	29
2-3.	A, A1 and J1 Boards Removal.....	12	5-4.	Semiconductors.....	62
2-4.	B1 and V Boards Removal.....	13			
2-5.	Service Position.....	13	6. EXPLODED VIEWS		
2-6.	Picture Tube Removal.....	14			
3. SET-UP ADJUSTMENTS					
3-1.	Beam Landing.....	15			
3-2.	Convergence.....	16			
3-3.	Focus.....	18			
3-4.	White Balance.....	18			

SAFETY-RELATED COMPONENT WARNING !!

COMPONENTS IDENTIFIED BY SHADING AND MARK  ON THE SCHEMATIC DIAGRAMS, EXPLODED VIEWS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY.

How to Receive NICAM TV Programmes

This TV is capable of receiving NICAM, which is a newly developed digital stereo broadcast for TV programmes.

NICAM programmes are broadcast in three ways: stereo, bilingual or monaural sound besides the regular (FM mono) sound. You can select the sound you want to hear by pressing the A/B button.

Action	Result
Press A/B on the Remote Commander.	The NICAM sound mode changes respectively. The selected sound mode differs depending on the broadcast.

The selected sound mode

NICAM sound being broadcast	The sound you hear
Stereo	Stereo → Regular → Stereo (etc.)
Bilingual	A → B → Regular → A (etc.)
Monaural	A → Regular → A (etc.)

On-screen indications and the NICAM indicator

The selected mode (STEREO, MONAURAL, SOUND-A or SOUND-B) appears on screen, and the NICAM indicator on the TV lights up as indicated in the following chart:

The sound being broadcast	The selected sound	NICAM indicator	Indications on the screen
NICAM+Regular	Stereo	×	STEREO
	A	×	SOUND-A
	B	×	SOUND-B
	Regular	×	MONAURAL
Regular	Regular	○	○

× means that the indicator lights up or the indication appears.

○ means that the indicator does not light up or the indication is not displayed.

The sound heard when you turn on the TV

Depending on the NICAM sound programme, the sound heard when you turn on the TV is different.


NICAM sound programme	The sound heard
NICAM sound and the regular sound are the same	NICAM sound
NICAM sound and the regular sound are different	Regular sound

Note) The layout, etc., will be slightly different from the operating instructions packed with the units.

SECTION 1 GENERAL


Turning the TV unit ON and OFF

After you have completed the basic preparation your TV is ready to be connected to the mains power supply (220/240V~, 50Hz).



Turning the TV unit ON	
Action	Result
1 Press on the TV.	The TV will turn on. Note: If the screen remains blank, the TV may be in the standby mode. Press to switch it on.

Turning the TV unit OFF	
A Temporarily	
Press to enter the standby mode.	The TV will be in the standby mode. To return to the TV mode press .
B Completely	
Press on the TV set.	The TV will be turned off.




TV channel presetting

After installing the TV set, TV channels must be preset.

TV broadcasting stations broadcast their programmes on certain fixed frequencies (channels). In order to receive these programmes it is necessary to search for the relevant broadcasting station and to set record it as a channel. The "programme number" is the number that the user decides to associate with a certain channel. For channel settings there are 60 positions available in the memory. In this way all stations broadcasting within the user's country can be received and recorded as a channel.

TV channels automatic presetting

If you are unfamiliar with the transmission frequency of the channels you wish to preset, refer to the section "TV channels automatic presetting". However, if you want to tune them using the frequency of each channel, go to the section "Direct TV channel setting".
To select a button on the "complete" side, take out the remote control unit from its case to reveal the preset buttons, as shown in the illustration.




Note: These buttons should be used in preset mode only.

Operation	Result
1 Press to begin the preselection.	The programme number flashes.
2 Press PROGR + or the remote control unit number buttons to select the channel number to which you want to preset the station. NOTE: To select a 2-figure number press the button. E.g., if you wish to select number 23, press first, and then 2 and 3.	The programme number on the screen changes.
3 To search for broadcasting stations press + and - buttons.	When a broadcasting station is tuned correctly, the search will stop. If you want to skip it, press or again.
4 Press to memorize the channel to that which the broadcasting station is tuned.	All data disappears from the screen.
5 To memorize other broadcasting stations repeat steps from 1 to 4.	

TV channel presetting

Direct TV channel setting




Operation	Result
1 Press → to begin the presetting. 	The programme number begins to flash on the screen.
2 Press PROG + /- or the number buttons on the remote control unit to select the channel number to which you want to preset the station. Note To select a 2-figure number press +/- button. E.g., if you wish to select number 23, press +/- first, and then 2 and 3.	The programme number on the screen changes.
3 Press C. If you wish to select a cable station, press C twice.	Indication "C-" ("S-" for cable stations) flashes on the screen
4 By using the number buttons of the remote control unit select the channel number, always with two figures (for "4" press "04"). Note: Press the second number within 5 seconds of the first. After 5 seconds the operation is cancelled.	The channel number changes on the screen. Note: In case of mistake, the "X" letter appears on the screen. Repeat once more the operation of step 4.
5 Press ◇ to memorize the channel to which the station is tuned. 	All indications disappear from the screen.

To memorize other broadcasting stations repeat the above procedure.

Broadcasting station identification

By associating a name with a certain broadcasting station it is possible to avoid having to remember, each time, in which channel number that particular station has been memorized.

Five different characters are available for station identification.



Operation	Result
1 By using PROG + or -, or the number keys of the remote control unit, select the programme number to be set for identification. 	The programme number to be set for identification appears on the screen.
2 Press → 	The number flashes on the screen.
3 Press □ 	The first indication line flashes on the screen.
4 Press the + or - buttons to select a letter of the alphabet, a number, or a blank space. 	Alphabetic letters, numbers or a blank space (" ") appear on the screen, in that order.
5 Press □ 	In this way the first character has been set, and the following position now flashes on the screen.
6 Repeat steps 4 and 5, and fill all five available spaces.	
7 Press ◇ 	All indications disappear from the screen, except the programme number. All indications remaining on the screen have been memorized.

Temporary channel tuning











It is possible to temporarily memorize a channel, even if it has not been preset.

Operation	Result
1 Press C. Press C twice for a cable station.	"C" ("S" for cable stations) indication appears on the screen.
2 Using the number keys of the remote control unit select the channel number, always with two figures (e.g., "04" for channel "4").	The channel will be received, but it will not be set as a programme number.

Basic functions

Skipping channels

Using the **PROGR +/–** buttons you can skip unused programme numbers. However, the skipped numbers may still be called up using the number buttons.

Operation	Result
1 Press → to begin presetting. 	 The programme number begins to flash on the screen.
2 By using the PROGR + and – buttons, or the number keys of the remote control unit, select the programme number you wish to skip.   	 The programme number changes.
3 Press C00 . 	 Under the programme number, the lowest channel number appears.
4 Press ◇ . 	 All indications under the programme number disappear from the screen. The skipped programme number will be memorized.

Manual fine tuning




If the picture is not perfect, it is possible to fine tune it manually.


Operation	Result
Press ↔ + or – repeatedly until the picture is at the optimum.	The indication ←F→ appears on the screen.
Press → to start preselection.	The programme number starts flashing on the screen.
Press ◇ .	Manual fine tuning has been memorized.

Note: Manual fine tuning will be reset when the channel is selected again.

To open, press the arrow .







  






This section introduces you to the basic control functions which are available on the "simple" side of the remote control unit.

Programme selection

Before selecting programmes make sure that TV channels have been memorized.

Operation	Result
Press PROGR +/– buttons or the number keys of the remote control unit. To select a 2-figure number press /– button. E.g., if you wish to select number 23, press /– first, and then 2 and 3.   	 The selected programme number appears on the screen.

Volume control

Operation	Result
Press ▲ + or – .  	 The volume indication appears on the screen.

Use of additional functions

Use of other functions with the TV set buttons

It is also possible to select programmes and to adjust the volume by using **P**, **→**, **←** and **↔** + or – buttons, located on the front panel of the TV set. In this case, press first **P**, **→**, **←** until the indication **P** (channel) or **▲** (volume) appears on the screen, and then press **↔** + or – buttons.

Use of teletext service



Press **Ⓢ**. To return to the TV mode, press **○**. For further information on the teletext service see page 12.

Selection of the video input

Press **Ⓢ**. To return to the TV mode, press **○**. For further details, refer to page 16.

Special functions

This section explains the use of functions for adjusting pictures and sound. Use the "complete" side of the remote control unit.



Use of special functions

The following functions can be used.

Function	Operation	Reset
Indication display	Press G	Press G again.
Sound muting	Press M	Press M again.
Language selection for bilingual programmes.	Press A/B. The selected language is displayed by the relevant indication on the screen.	Press A/B.
Sound adjustment for music programmes.	Press M	Press M again.
Use of special sound effects.	Press S	Press S again.
Time display (only during teletext broadcasting).	Press T	Press T again.

Picture and sound adjustment

Although the picture and sound have been adjusted at the factory, you might want to adjust them to your own taste. To do this, please follow the steps below.

To Adjust:	Press:	Then:	Result: (+ -- -)
Picture:			
Colour intensity	C	+	More -- Less
Contrast	I		More -- Less
Brightness	B	-	Bright -- Dark
Hue (for NTSC only)	H		Reddish -- Greenish
Sharpness	S		More -- Less
Sound:			
Bass	B	+	More -- Less
Treble	T		More -- Less
Balance	B	-	Left -- Right


To reset the picture and sound to factory set levels, press **→←**.

On the set: Press the **→←** and **+/-** buttons simultaneously.

Use of the teletext service



Through the teletext service a great deal of information can be received at any time. Broadcasting stations make this service available through TV broadcasts. To use the teletext service, use the green keys on the "complete" side of the remote control unit. When the "simple" side of the remote control unit is used, only the basic functions are available.

How to display teletext service






Operation	Result
1 Select the channel you want to watch.	The channel changes on the screen.
2 Press T	 If there is no teletext signal, the indication "Page 100" appears on the screen.
3 Use the number keys of the remote control unit to insert the three figures corresponding to the desired teletext page. Note In case of a mistake, press any three numbers, and then repeat the operation with the correct numbers.	The selected page number appears on the screen. After a few seconds, the selected page appears on the screen.
To return to normal TV programmes: Press O . To change teletext channel: First press O to return to the TV mode, and then repeat steps 1 to 3.	


Note: A weak TV signal may cause trouble in the use of teletext.

Use of special teletext functions

Required function	Operation	Result (on the screen)
Page index required.	Press T (INDEX).	 Page index appears.
Sub-pages required (page 888).	Press O .	The sub-page appears (page 888).
Access to previous or following pages.	Press S (PAGE +) or M (PAGE -).	 The preceding or the following page appears.

Use of the teletext service

Required function	Operation	Result (on the screen)
Superimposition of the teletext on the TV programme.	In the TV mode, press Ⓢ twice. To return to the normal teletext function press Ⓢ again.	 Teletext information will appear superimposed on the TV programme.
To prevent page changes due to page updating.	Press Ⓢ (STILL). Press Ⓢ (TXT/MIX) to return to the normal function.	 The Ⓢ (STILL) symbol appears on the screen.
Magnification of teletext characters.	Press Ⓢ once to magnify the upper half of the screen. Press twice to magnify the lower half of the screen. By pressing the button three times the normal vision is restored.	 The upper or the lower half of the page is magnified.
Display of hidden information (answers to quizzes, etc.).	Press Ⓢ (RIV). Press again to hide the answers.	 The information is displayed.
Watching a programme while the teletext searches for the required page.	1. Ask again for the page.	The number is displayed.
	2. Press Ⓢ	TV programme is displayed.
	3. When the required page has been found, the page number will be displayed.	 P201
	4. Press Ⓢ to display the page.	The desired page will be displayed.
Display of a page at a preset time.	1. Request the page.	The selected page will be displayed.
	2. Press Ⓢ (MEM.T).	In the lower part of the screen the indication "T*****" appears.
	3. Set the required time by using the number keys, and by inputting four figures (e.g. 0730 for "7:30").	The required time is displayed on the screen.
	<p>To watch TV programmes until a preset time Press Ⓢ (CANC.). At the required time, the selected page appears in the upper part of the screen. Press Ⓢ to display the page.</p> <p>To cancel the request Display the teletext page and then press Ⓢ (CANC.M.).</p>	



Use of the FASTEXT function

The FASTEXT function allows rapid access, at the touch of a single button, to the teletext functions. In the lower part of the screen, a colour coded index will be displayed when a FASTEXT teletext page is broadcasted. Each colour corresponds to the colored keys on the remote control unit.

Operation

Operation	Result
Press one of the coloured keys on the remote control unit corresponding to the coloured indications of the FASTEXT teletext page.	The selected teletext page appears on the screen.

Note:

The correct use of the FASTEXT function depends on the signal being broadcast by the TV stations. Some TV stations may not broadcast FASTEXT teletext signal.

Connections and optional functions


This TV set may be connected to other audio/video machines, such as videocameras, VTRs, videodisc players, or stereo systems.

Connection to an external audio/video system


This TV set incorporates three groups of connectors, for input and output to the TV signal. Each group has the following characteristics.

Connector	Input signal	Output signal
⊖-1	Normal audio/video signal or RGB signal	TV tuner audio/video signal
⊖-2/⊖-3	Normal audio/video signal and S-video signal	Audio/video signal from a selectable source
⊖-3, ⊖, -⊖ front panel	Normal audio/video signal and S-video signal	No signal


Connection of a TV set



Connection of an audio unit




Connection to a computer with RGB output



Temporary connection of video apparatus

For a temporary connection (e.g. of a videocamera) use the front panel terminals.



Connection of a videotape recorder through the T connector

Connect the antenna input (AERIAL-IN) of the TV set to the antenna output (AERIAL-OUT) of the videotape recorder.

S-video input (Y/C input)

The video signal is formed by two separate signals: the luminance (Y) and the chrominance (C). Through the separation of the two signals it is possible to improve picture quality (luminance in particular), preventing reciprocal interference. This TV set features two S-video sockets able to directly receive this type of signal.

Pictures with distortion

Move the TV set away from the videotape recorder if pictures or sound become distorted.

Connections and optional functions

Video programme playback

Using the input selector, pictures coming from a videotape recorder connected to the TV sets input may be played back.

Operation

Operation	Result
Select the desired video input by pressing ⊖ repeatedly.	⊖1 The symbol of the selected input appears on the screen (see table below).
Press ⊖ button to return to TV mode.	

Selectable inputs

Symbol	Selected input
⊖1	Audio/video signal from ⊖-1 connector.
⊖	RGB signal from ⊖-1 connector.
⊖2	Audio/video signal from ⊖-2/⊖-3 connector.
⊖2	S-video signal (from a VTR with S-video output) from ⊖-2/⊖-3 connector.
⊖3	Audio/video signal from ⊖, -⊖ connector located on the front panel.
⊖3	S-video signal from S-video ⊖ (4 pin) connector located on the front panel.

Input can be selected also with the ⊖-1-⊖ buttons of the TV set.

In this case, first select ⊖, and then press the + / - buttons to select the desired input.

Selection of video output



The ⊖-2/⊖-3 connector may output 4 video signals. Select the outgoing video signal in the following way.

Operation

Operation	Result
Press ⊖ repeatedly to select the desired video output.	1⊖ The selected video output symbol appears on the screen (see the table following).





Output signal

Symbol	Selected output
1⊖	Audio/video signal from ⊖-1 connector.
2⊖	Audio/video signal from ⊖-2/⊖-3 connector.
3⊖	Audio/video signal from ⊖ and -⊖ connectors.
TV⊖	Audio/video signal from T-type antenna connector T.



General information

Components identification



General information

This section briefly describes controls of the TV set and the remote control unit, and their relevant functions.

A TV set front panel	
Indication	Description
	Power switch
	Standby switch
A - B	Bilingual function indications
	Headphones connector (stereo mini-jack)
	Input connectors (S-video/video/audio)
	Function selector (programme/volume/input)
	Function adjustment keys


B TV set rear panel	
Indication	Description
	Speaker connectors (upper: left speaker; lower: right speaker)
	Connector 2, Euro AV (SCART, 21-pin). S-video In/video In/TV/video out signals.
	Connector 1, Euro AV (SCART, 21-pin). RGB In/video In/TV/out signals.
	Audio output connectors (RCA pin)
	Antenna connector (of IEC standard)

C Remote control unit — simplified side	
Indication	Description
	Input selector
	Teletext service key
	FASTEXT operation buttons
	TV set power switch and TV mode selector
	Standby key
1,2,3,4,5, 6,7,8,9,0	Number keys
+/-	Channel selection key/ 2-figure programmes
	Volume adjustment key
PROGR +/-	Programme selection key


D Remote control unit — complete side	
Indication	Description
	Sound muting key
	Standby key
1,2,3,4,5, 6,7,8,9,0	Number keys
	Input selector
	TV set power switch and TV mode selector
	Output selector
	Teletext key
	Music programme key
A/B	Bilingual programmes language selection
+/-	Channel selection key/ 2-figure programmes
C	Channel direct selection key
	Special sound effect key
	Time display
	Teletext operation keys
	FASTEXT operation buttons
	Display key
	Reset key
	Volume adjustment keys
PROGR +/-	Programme selection keys
	Image and audio adjustment keys
VIDEO 1/2/3, MDP	Video unit selector
	Video units function key
Coo	Programme cancelling key
	Channel presetting key
- +	Channel tuning keys
	Channel storing keys
	Broadcasting stations identification key

SECTION 2 DISASSEMBLY


2-1. REAR COVER REMOVAL




2-2. CHASSIS ASSEMBLY REMOVAL



2-3. A, A1 AND J1 BOARDS REMOVAL




2-4. B1 AND V BOARDS REMOVAL




Note : 10 pin extension cable (S-0945-001-0)

2-5. SERVICE POSITION

- * Remove the connector bracket from the main chassis assembly and then perform the following servicing.
(Refer to 2-2. CHASSIS ASSEMBLY REMOVAL.)




2-6. PICTURE TUBE REMOVAL



• REMOVAL OF ANODE-CAP

• REMOVING PROCEDURES





① Turn up one side of the rubber cap in the direction indicated by the arrow ③.

② Using a thumb pull up the rubber cap firmly in the direction indicated by the arrow ④.

③ When one side of the rubber cap is separated from the anode button, the anode-cap can be removed by turning up the rubber cap and pulling up it in the direction of the arrow ⑤.

• HOW TO HANDLE AN ANODE-CAP

- ① Don't hurt the surface of anode-caps with sharp shaped material!
- ② Don't press the rubber hardly not to hurt inside of anode-caps!
A material fitting called as shatter-hook terminal is built in the rubber.
- ③ Don't turn the foot of rubber over hardly!
The shatter-hook terminal will stick out or hurt the rubber.



SECITON 3

SET-UP ADJUSTMENTS

- When complete readjustment is necessary or a new picture tube is installed, carry out the following adjustments.
- Unless there is specific instruction to the contrary, carry out these adjustments with the rated power supply.
- Unless there is specific instruction to the contrary, set the controls and switches this way :
 - Contrast80%
(or remote control normal)
 - ⚙ Brightness50%

- Carry out the following adjustments in this order:
 1. Beam landing
 2. Convergence
 3. Focus
 4. White balance

Note : Testing equipment required

1. Color bar/pattern generator
2. Degausser
3. DC power supply
4. Digital multimeter
5. Oscilloscope

Preparations :

- In order to reduce the influence of geomagnetism on the set's picture tube face it east or west.
- Switch on the set's power and degauss with the degausser.

3-1. BEAM LANDING

1. Input the white signal with the pattern generator.
Contrast } normal
Brightness }
2. Position neck ass'y as shown in Fig 3-2.
3. Set the pattern generator raster signal to red.
4. Move the deflection yoke to the rear and adjust with the purity control so that the red is at the center and the blue and the green take up equally sized areas on each side.
(See Figures 3-1 through 3-3.)
5. Move the deflection yoke forward and adjust so that entire screen is red. (See Figure 3-1.)
6. Switch the raster signal to blue, then to green and verify the condition.
7. When the position of the deflection yoke has been decided, fasten the deflection yoke with the screws.
8. If the beam does not land correctly in all the corners, use a magnet to adjust it.
(See Figure 3-4.)






Fig. 3-1




3-2. CONVERGENCE

Preparations :


- Before starting this adjustment, adjust the focus, horizontal size, and vertical size.
- Minimize the brightness setting.
- Provide dot pattern.

(1) Horizontal and vertical static convergence







1. (Moving horizontally), adjust the H.STAT control so that the red, green, and blue points are on top of each other at the center of the screen.
2. (Moving vertically), adjust the V.STAT magnet so that the red, green, and blue points are on top of each other at the center of the screen.
3. If the H.STAT variable resistor cannot bring the red, green, and blue points together at the center of the screen, adjust the horizontal convergence with the H.STAT variable resistor and the V. STAT magnet in the manner given below.
(In this case, the H.STAT variable resistor and the V. STAT magnet influence each other)


- Tilt the V.STAT magnet and adjust the static convergence by opening or closing the V. STAT magnet.



4. If the V.STAT magnet is moved in the direction of the ① and ② arrows, the red, green, and blue points move as shown below.




● Operation of BMC (Hexapole) Magnet



- The respective dot positions resulting from moving each magnet interact, so be sure to perform adjustment while tracking.

Use the H.STAT VR to adjust the red, green, and blue dots so they coincide at the center of screen (by moving the dots in the horizontal direction).




(2) Dynamic convergence adjustment

Preparations :


Before starting this adjustment, adjust the horizontal static convergence and the vertical static convergence.

1. Slightly loosen the deflection yoke screws.
2. Remove the deflection yoke spacer.


3. Move the deflection yoke as shown in the figure below and optimize the convergence.
4. Tighten the deflection yoke screws.
5. Install the deflection yoke spacer.



(3) Screen corner convergence




Install the permalloy assembly for the section with faulty.



Permalloy

3-3. FOCUS

Adjust the focus to optimize the screen.



3-4. WHITE BALANCE

[Screen G2 setting]

1. Input the dot signal from the pattern generator.
2. Set the picture brightness control to its lowest level.
3. Apply 170V DC to the R, G, and B cathodes with an external power supply.
4. While watching the picture, adjust G2 control RV701 (Screen) to the point just before the return lines disappear.


[White balance adjustment]

1. Input an all-white signal from the pattern generator.
2. Set the picture brightness and color controls to their normal levels.
3. Use the RV704 (B Drive) and RV703 (G Drive) to adjust white balance.

In the adjustments below, have the picture color and brightness settings at their normal levels unless there is a specific instruction to the contrary.

SECTION 4 CIRCUIT ADJUSTMENTS

4-1. A BOARD ADJUSTMENTS




A BOARD (COMPONENT SIDE)

TUNER AGC ADJUSTMENT (VIF101, RV1)

1. Align with an appropriate signal between stations.
2. Adjust RV1 so that snow noise and cross modulation just disappear from the picture.

IFG5.5S SIF



IFG5.5S SIF -component side-


STEREO SEPARATION ADJUSTMENT (RV1)

1. Input stereo signals. (L-CH 400Hz, R-CH 1KHz)
2. Check the stereo indicator.
3. Connect an oscilloscope to pin ⑧ (CH1) of CN1 through a band pass filter of 1KHz
4. Adjust RV1 so that 1KHz voltage goes down to the minimum.

H FREQ (RV2)

1. Input a PAL COLOR BAR signal, then connect a jumper between pin ⑫ IC4 and GND.
2. Connect a frequency counter to pin ④ IFG5.5S (HP) of CN1 through a probe of 10 : 1.
3. Adjust RV2 (H.FREQ) $15.625 \pm 50\text{Hz}$.
4. After adjustment, remove the jumper.

4-2. A1 BOARD ADJUSTMENT




A1 BOARD (COMPONENT SIDE)

DATA CLOCK Adjustment (CV1101)

1. Tune in a no signal.
2. Connect a frequency counter to pin ⑩ of IC1102 (PCLK) through a probe of 10:1.
3. Adjust CV1101 (DATA CLOCK) so that frequency becomes $728.022\text{KHz} \pm 1\text{Hz}$.

4-4. D BOARD ADJUSTMENTS



D BOARD (COMPONENT SIDE)

+B ADJUSTMENT (RV501)


1. Connect the digital multimeter to TP91.
2. Adjust RV501 to obtain $135 \pm 0.2V$.

ST-BY +B ADJUSTMENT (RV601)

1. Put the system into \odot standby mode (remote commander).
2. Connect the digital multimeter to TP91.
3. Adjust RV601 to obtain $135 \pm 3V$.
4. Take the system out of \odot standby mode (remote commander).

H.PHASE ADJUSTMENT (RV502)


1. Input a PAL color bar signal.
2. Set the picture and brightness controls to their normal levels.
3. Set RV1508 (H.CENT) to its mechanical center.
4. Connect the oscilloscope to pin ⑪ (SCP) of IC 501.
5. Rotate RV502 to adjust to $H \pm 0.1\mu s$.









Standard of H. PHASE

Model Size	H
25"	$5.1\mu s$
29"	$5.5\mu s$


4-5. J1 BOARD ADJUSTMENTS



J1 BOARD (COMPONENT SIDE)

RV1508
H. CENT (HORIZONTAL CENTER)RV1504
H. SIZE (HORIZONTAL SIZE)RV1506
V. CENT (VERTICAL CENTER)RV1507
V. SIZE (VERTICAL SIZE)RV1509
V. ANGLE (VERTICAL ANGLE)RV1503
PIN AMP (PINCUSHION AMPLIFIER)RV1502
PIN PHASE (PINCUSHION PHASE)RV1501
PIN. COR (PINCUSHION CORRECT)RV1505
CORNER COR (CORNER CORRECT)

4-6. V BOARD ADJUSTMENT



RGB LEVEL ADJUSTMENT (RV01)

1. Maximize the picture setting.
2. Adjust RV01 so that the RGB output is 0.75V.

4-7. SECONDARY ADJUSTMENTS

SUB BRIGHTNESS ADJUSTMENT

1. Set the system to receive a test pattern.
2. Press → • ← on the remote commander to put the system into normal mode.
3. Switch off the power.
4. While depressing the adjusting buttons + and - simultaneously, turn on the power. (SUB mode is obtained)
5. Minimize the ● contrast setting.
6. Adjust the ☼ brightness control so that the gray scale 0 IRE section is cut off completely and the 20 IRE section is barely glowing.
7. Depress the ◇ (store) button of the remote commander. (SUB mode is released)

If there is no test color pattern



1. Set the system to receive a color pattern.
 2. Press → • ← on the remote commander to put the system into normal mode.
- Set the ● color to its normal state.


3-5. Steps are the same as above.


6. Since 20 IRE is nearly blue, adjust the ☼ brightness control so that the blue barely glows.
7. Same as step 7 above.
8. Press → • ← on the remote commander to put the system into normal mode.

SUB COLOR ADJUSTMENT


1. Set the system to receive color bars.
2. Press → • ← on the remote commander to put the system into normal mode.
3. Cut off the power.
4. While depressing the adjustment buttons + and - simultaneously, turn on the power. (SUB mode is obtained).
5. Adjust the color control so that the B out waveform (pin ⑤ of C board connector CNC72) is as shown in the figure below.
6. Depress the ◇ (store) button of the remote commander. (SUB mode is released)













5-2. CIRCUIT BOARDS LOCATION



5-3. SCHEMATIC DIAGRAM AND PRINTED WIRING BOARDS

Note: The components identified by shading and mark  are critical for safety. Replace only with part number specified.


- Note :
- All capacitors are in μF unless otherwise noted.
pF: $\mu\mu\text{F}$ 50WV or less are not indicated except for electrolytics.
 - Indication of resistance, which does not have one for rating electrical power, is as follows.
- Pitch : 5mm
Rating electrical power: 1/4W
- Chip resistor is in 1/10W.
 - All resistors are in ohms. $\text{k}\Omega = 1000\Omega$, $\text{M}\Omega = 1000\text{k}\Omega$
 -  : nonflammable resistor.
 -  : fusible resistor.
 - Δ : internal component.
 -  : panel designation and adjustment for repair.
 - All variable and adjustable resistors have characteristic curve B.unless otherwise noted.
 - All voltages are in V.
 - Readings are taken with a 10M Ω digital multimeter.
 - Readings are taken with a color-bar signal input.
 - Voltage variations may be noted due to normal production tolerances.
 -  : B+ line.
 -  : signal path. (RF)

Reference information

RESISTOR	: RN	METAL FILM
	: RC	SOLID
	: FPRD	NONFLAMMABLE CARBON
	: FUSE	NONFLAMMABLE FUSIBLE
	: RS	NONFLAMMABLE METAL OXIDE
	: RB	NONFLAMMABLE CEMENT
	: RW	NONFLAMMABLE WIREWOUND
	: *	ADJUSTMENT RESISTOR
COIL	: LF-8L	MICRO INDUCTOR
CAPACITOR	: TA	TANTALUM
	: PS	STYROL
	: PP	POLYPROPYLENE
	: PT	MYLAR
	: MPS	METALIZED POLYESTER
	: MPP	METALIZED POLYPROPYLENE
	: ALB	BIPOLAR
	: ALT	HIGH TEMPERATURE
	: ALR	HIGH RIPPLE





A [TUNER, SIF, VIF] **F** [AC IN, POWER SW.] **J1** [AUDIO CONTROL, AV INPUT, Y/C INPUT, SCART VIDEO OUT, EAST-WEST CORRECTION] **J2** [SPEAKER TERM]

- A Board -




[SIRCS RECEIVER,]
[INDICATOR]


—VM BOARD— (KV-C2951D ONLY)




-H1 Board-




-H2 Board-









• WAVEFORMS A BOARD



• A BOARD

IC103	PCF8574	EXPANSION
Q113	25C2412K	AUDIO
Q114	25C2412K	AUDIO
Q115	25C2412K	AUDIO
Q116	25C2412K	AUDIO
Q125	0TC144ES	MUTE
Q126	0TA144EK	MUTE
Q181	25C2412K	NICAM



• H2 BOARD


IC1651	SBX1610-11	INFRARED RECIVER
01651	L0-201VR	AUDIO CHANNEL A INDICATOR
01652	L0-201VR	AUDIO CHANNEL B INDICATOR
01654	L0-201VR	RESET

• VM BOARD (KV-C2951D ONLY)


Q751	JC501	REF AMP
Q752	JC501	REF AMP
Q753	25B734	PUSH-PULL OUT
Q754	25B774	PUSH-PULL OUT

J₁


AUDIO CONTROL.
AV INPUT, Y/C INPUT.
SCART VIDEO OUT.
EAST-WEST CORRECTION



A BOARD IC103 PCF8574



H2 BOARD IC1651 SBX1610



- J1 B

* MAR

KV-C3

C1512
C1514


C1514
C1515

01513	
-------	--

R151.5

R1520

R1550




• J1 BOARD

* MARK


KV-C2551D	KV-C2951D
C1512 0.0068 400V	C1512
C1514 0.022 250V	C1514
C1515 820P	C1515
R1515 680K	R1515
R1520 470K	R1520 390K
R1550 JW	R1550 1 1W :RS

NOT MOUNTED

H2 BOARD IC1651 SBX1610-11




J1 BOARD IC201 TDA6200




• J1 BOARD

IC201	TDA6200	AUDIO CONTROL
IC1401	CXA1114P	AV SW
IC1402	TEA2014A	SCART VIDEO OUT
IC1403	MC14053BCP	COMPOSITE Y/C SW
IC1501	TEA2031A	EAST-WEST CORRECTION
Q201	2SC2412K	AUDIO R BUFF
Q202	2SC2412K	AUDIO L BUFF
Q1401	2SA1037K	VIDEO OUT
Q1402	2SC2412K	VIDEO OUT BUFF
Q1403	2SC2412K	Y OUT BUFF
Q1404	2SA1037K	C OUT BUFF
Q201	MTZJ-T-77-9.1C	PROTECT
Q202	MTZJ-T-77-9.1C	PROTECT
Q205	MTZJ-T-77-7.5C	PROTECT
Q206	MTZJ-T-77-7.5C	PROTECT
Q1401	MTZJ-T-77-7.5C	PROTECT
Q1403	MTZJ-T-77-7.5C	PROTECT
Q1404	MTZJ-T-77-7.5C	PROTECT
Q1405	MTZJ-T-77-7.5C	PROTECT
Q1406	MTZJ-T-77-7.5C	PROTECT
Q1407	MTZJ-T-77-10C	PROTECT
Q1408	MTZJ-T-77-9.1C	REG
Q1409	MTZJ-T-77-9.1C	PROTECT
Q1410	MTZJ-T-77-9.1C	PROTECT
Q1415	MTZJ-T-77-7.5C	PROTECT
Q1418	MTZJ-T-77-7.5C	PROTECT
Q1419	MTZJ-T-77-7.5C	PROTECT
Q1420	MTZJ-T-77-7.5C	PROTECT
Q1421	MTZJ-T-77-7.5C	PROTECT
Q1422	MTZJ-T-77-7.5C	PROTECT
Q1423	MTZJ-T-77-7.5C	PROTECT
Q1424	MTZJ-T-77-7.5C	PROTECT
Q1425	MTZJ-T-77-7.5C	PROTECT
Q1426	MTZJ-T-77-7.5C	PROTECT
Q1501	RGP10G	PROTECT
Q1502	ISS133	DECOUPLING H SIZE
Q1503	ISS133	CLIPPING V PARABORA
Q1504	ISS133	CLIPPING H PULSE
Q1505	ISS133	REG
Q1506	MTZJ-T-77-36D	PROTECT
Q1507	ISS133	PROTECT
Q1510	ISS133	REG


• WAVEFORMS J1 BOARD




J1 BOARD IC1401 CXA1114P




J1 BOARD IC1402 TEA2014A



J1 BOARD IC1403 MC14053BCP



J1 BOARD IC1501 TEA2031A



• WAVEFORMS B1 BOARD

① PAL 5.4Vp-p (H)	① SECAM 4.8Vp-p (H)	① NTSC3.58/ NTSC4.43 5.6Vp-p (H)	② PAL 5.4Vp-p (H)
② SECAM 4.8Vp-p (H)	② NTSC3.58/ NTSC4.43 5.6Vp-p (H)	③ PAL 5.4Vp-p (H)	③ SECAM 5.0Vp-p (H)
③ NTSC3.58/ NTSC4.43 6.2Vp-p (H)	④ 10.5Vp-p (H)	⑤ PAL 0.4Vp-p (H)	⑤ SECAM 0.3Vp-p (H)
⑤ NTSC3.58/ NTSC4.43 0.6Vp-p (H)	⑥ PAL/SECAM 1.1Vp-p (H)	⑥ NTSC3.58/ NTSC4.43 1.2Vp-p (H)	⑦ PAL/SECAM 1.4Vp-p (H)
⑦ NTSC3.58/ NTSC4.43 1.4Vp-p (H)	⑧ PAL 0.4Vp-p (H)	⑧ SECAM 1.0Vp-p (H)	⑧ NTSC3.58/ NTSC4.43 0.8Vp-p (H)
⑨ PAL 0.7Vp-p (H)	⑨ SECAM 1.4Vp-p (H)	⑨ NTSC3.58/ NTSC4.43 0.85Vp-p (H)	⑩ SECAM 0.2Vp-p (H)
⑪ SECAM 1.2Vp-p (H)	⑫ PAL 0.16Vp-p (H)	⑫ SECAM 0.2Vp-p (H)	⑫ NTSC3.58/ NTSC4.43 0.3Vp-p (H)
⑬ PAL 1.0Vp-p (H)	⑬ SECAM 0.8Vp-p (H)	⑬ NTSC3.58 0.9Vp-p (H)	⑬ NTSC4.43 0.95Vp-p (H)
⑭ PAL 0.8Vp-p (H)	⑭ SECAM 0.7Vp-p (H)	⑭ NTSC3.58 0.6Vp-p (H)	⑭ NTSC4.43 0.8Vp-p (H)
⑮ PAL 0.7Vp-p (H)	⑮ SECAM NTSC3.58 NTSC4.43 0.5Vp-p (H)	⑯ 0.9Vp-p (H)	⑰ PAL 1.9Vp-p (H)
⑰ SECAM NTSC3.58 NTSC4.43 0.1Vp-p (H)	⑱ PAL 0.2Vp-p (H)	⑱ SECAM 0.8Vp-p (H)	⑲ PAL 0.6Vp-p (H)
⑲ SECAM 0.8Vp-p (H)	⑲ NTSC3.58/ NTSC4.43 0.9Vp-p (H)		

As to the voltage value shown by the mark * on the Schematic Diagram, see the another list.

IC NO	PIN NO	PAL	SECAM	NTSC 3.38	NTSC 4.43
IC301	(5)	6.7	4.8	4.8	4.8
	(15)	8.9	7.0	7.0	7.0
	(19)	3.4	3.4	3.8	3.4
	(16)	6.6	6.6	6.0	6.3
	(1)	0.1	6.8	6.9	6.8
IC304	(5)	9.9	0	9.9	9.9
	(7)	4.6	0	4.6	4.6
	(8)	3.4	3.0	3.4	3.4
	(9)	3.4	3.0	3.4	3.4
	(10)	4.6	3.4	4.6	4.6
	(11)	2.3	3.1	3.1	2.3
	(12)	5.6	5.6	5.6	7.4
	(13)	7.5	7.5	5.7	5.7
	(25)	0.1	0.1	0.1	6.0
	(26)	0.1	0.1	6.0	0.1
	(27)	0.1	6.0	0.1	0.1
	(28)	6.0	0.1	0.1	0.1

Q NO		PAL	SECAM	NTSC 3.38	NTSC 4.43
Q338	B	2.4	3.9	3.9	3.9
	E	3.0	4.6	4.6	4.6
Q339	B	3.0	4.6	4.6	4.6
	E	2.4	3.9	3.9	3.9
Q341	B	0	0.6	0.4	0.1
	C	11.6	0	11.6	11.6
Q342	B	0	0	0.4	0
	C	11.7	0	11.7	11.7
Q343	B	3.4	5.4	5.3	5.3
	E	2.8	4.7	4.7	4.7
Q344	B	0	5.4	1.0	0.1
	E	4.4	4.8	1.5	4.5
Q345	B	5.0	0.1	1.9	5.0
	E	4.4	4.4	1.4	4.4
Q347	B	0.6	0	0	0
	C	0.1	11.9	11.9	11.9
Q348	B	0.1	0.1	1.0	0.1
	C	1.3	0.2	0.2	0.4

• B1 BOARD


IC301	TDA4580-V6	VIDEO PROCESSOR
IC302	TDA8442-N3	D/A CONVERTER
IC303	TDA4660T	1H DELAY
IC304	TDA4650WP	COLOR PROCESSOR
IC305	PC24M05HF	REGULATOR
IC306	HCF4052BM	Y/C SW
IC308	CX20061	Y INTERRUPT
IC310	CX02011Q	COMB CONTROL
IC311	MB40968PF	D/A CONVERTER
IC312	CXK1202Q	MEMORY
IC313	CXK1202Q	MEMORY
IC315	CX01175AM	A/D CONVERTER
Q301	25C2412K	CANAL +BLK
Q302	25C2412K	ON SCREEN DISPLAY SW
Q303	25C2412K	FAS PICTURE MUTE SW
Q304	25C2412K	ON SCREEN DISPLAY SW
Q305	DTA144EK	ANIT PRIORITY SCART
Q306	25C2412K	STBY SW
Q307	25C2412K	ABL
Q308	DTC124EK	MUTE
Q310	DTC124EK	SECAM SW
Q311	DTC124EK	SECAM SW
Q320	25C2412K	HUE BUFFER
Q321	2SA1037K	CLK AMP3
Q322	2SA1037K	CLK AMP2
Q323	25C2412K	CLK AMP1
Q324	25C2412K	CLK BUFFER
Q327	2SA1037K	Y OUT
Q328	2SA1037K	VIDEO IN
Q329	2SA1037K	Y IN
Q330	25C2412K	VIDEO BUFFER
Q331	2SA1037K	C OUT
Q332	2SA1037K	C IN
Q333	DTC124EK	Y/C SW
Q334	DTC124EK	Y SW
Q335	25C2412K	SECAM SW
Q336	25C2412K	NTSC (3.58) SW
Q337	25C2412K	NTSC (4.43) SW
Q338	2SA1037K	Y BUFFER
Q339	25C2412K	Y BUFFER
Q340	25C2412K	Y BUFFER
Q341	25C2412K	SECAM TRAP SW
Q342	25C2412K	NTSC TRAP SW
Q343	25C2412K	C OUT
Q344	25C2412K	SECAM SW
Q345	25C2412K	PAL/SECAM SW
Q346	25C2412K	Y IN
Q347	25C2412K	PAL SW
Q348	DTC124EK	NTSC (3.58) SW
Q350	25C2412K	CLK AMP
Q352	2SA1037K	VIDEO AMP
Q353	25C2412K	BUFFER
Q354	25C2412K	BUFFER
Q355	25C2412K	VIDEO AMP
Q356	2SA1037K	VIDEO BUFFER
Q357	2SA1037K	CLAMP BIAS
Q358	25C2412K	VIDEO CLAMP
Q359	2SA1037K	CLAMP BIAS
Q360	25C2412K	CLK BUFFER
Q361	25C2412K	CLK AMP
Q362	25C2412K	Y BUFFER
Q363	25C2412K	C BUFFER
Q364	2SA1037K	C BUFFER
Q365	2SA1037K	Y BUFFER
Q366	25C2412K	SHP BUFFER
Q367	25C2412K	Y BUFFER
Q368	25C2412K	SHP AMP
Q369	25C2412K	SHP AMP
Q370	25C2412K	SHP AMP
Q371	25C2412K	VM BUFFER
Q372	25C2412K	VM AMP
Q373	DTC124EK	SYSTEM SW
Q1301	DTC124EK	Y BUFFER
Q1302	25C2412K	Y BUFFER
Q1303	DTC124EK	VM MUTE
Q301	1MN10	ACO AT STBY
Q304	DAN212K	PROTECT
Q305	DAN212K	PROTECT
Q307	MA3110M	PROTECT
Q308	DAN212K	PROTECT
Q309	DAN212K	PROTECT
Q310	MA3110M	PROTECT
Q311	MA3110M	PROTECT
Q312	MA3110M	PROTECT
Q314	DA204K	PROTECT
Q318	DA204K	PROTECT
Q319	DA204K	PROTECT
Q320	DA204K	PROTECT
Q321	MA3056	REG
Q322	DAN202K	PROTECT
Q330	DAN212K	BIAS
Q331	DAP202K	Y/C SW
Q333	1MN10	SYSTEM SW
Q336	DAN202K	CORRECT SW
Q340	DA204K	VIDEO AMP
Q341	DAN212K	VIDEO AMP


• B1 BOARD


* MARK

KV-C2551D	KV-C2951D
R343 560 1/10W	R343 2.2k 1/10W
R1308 0 1/10W	R1308 4.7k 1/10W
B-73 OPEN	B-73 3P

KV-C2951D
343 2.2k 1/10W
1308 4.7K 1/10W
-73 3P









B1

VIDEO PROCESSOR, COLOR PROCESSOR,
Y/C SW, D/A CONVERTER, MEMORY,
CONVERTER


—B1 Board—

Note:

-
-



Note :
• : Pattern from the side which enables seeing.
• : Pattern of the rear side.



IC			
IC301	F-8	Q362	C-4
IC302	E-8	Q363	C-5
IC303	D-9	Q364	B-5
IC304	D-10	Q365	A-4
IC305	C-8	Q366	D-3
IC306	F-11	Q367	E-9
IC308	F-10	Q368	E-9
IC310	A-9	Q369	E-9
IC311	A-8	Q370	D-9
IC312	A-10	Q371	D-9
IC313	A-9	Q372	D-9
IC315	A-11	Q373	F-10
		Q1301	E-3
		Q1302	E-3
		Q1303	F-3


TRANSISTOR		DIODE	
Q301	G-3	D301	E-9
Q302	F-3	D304	G-8
Q303	F-3	D305	F-8
Q304	G-4	D307	F-10
Q305	E-4	D308	F-9
Q306	G-2	D309	G-10
Q307	G-4	D310	E-8
Q308	F-3	D311	E-8
Q310	C-1	D312	E-8
Q311	C-2	D314	E-8
Q320	D-2	D318	E-8
Q321	C-3	D319	E-8
Q322	C-3	D320	E-9
Q323	C-3	D321	D-8
Q324	C-3	D322	F-2
Q327	F-1	D330	D-9
Q328	G-1	D331	F-10
Q329	G-1	D333	E-10
Q330	F-2	D336	C-11
Q331	F-1	D340	B-10
Q332	G-2	D341	B-11
Q333	F-2		
Q334	D-2		
Q335	D-1		
Q336	D-2		
Q337	D-2		
Q338	E-1		
Q339	E-2		
Q340	F-2		
Q341	E-1		
Q342	E-2		
Q343	F-1		
Q344	E-1		
Q345	F-1		
Q346	D-3		
Q347	F-1		
Q348	E-2		
Q350	B-3		
Q352	B-2		
Q353	B-1		
Q354	B-1		
Q355	C-2		
Q356	C-1		
Q357	B-1		
Q358	B-1		
Q359	B-1		
Q360	B-3		
Q361	C-3		

VARIABLE RESISTOR	
RV301	C-11


TRIMMER	
CT301	C-9
CT302	C-9

COIL	
L303	D-11
L308	E-11
L312	D-10
L313	E-11


B1 BOARD IC301 TDA4580-V6




B1 BOARD IC302 TDA8442-N3




B1 BOARD IC303 TDA4660T




D BOARD IC251/261 TDA2050




D BOARD IC501 TEA2028B



D BOARD IC502 TDA8170



D BOARD IC601 TEA2260




D [TUNING CONTROL, POWER CONTROL,
AUDIO OUT, H/V OUT]




The circuit indicated as left contains high voltage of over 600 Vp-p. Care must be paid to prevent an electric shock in inspection or repairing.

-D Board-


IC		D013	D-2
IC001	B-1	D271	C-5
IC002	D-2	D272	D-5
IC003	C-1	D501	G-6
IC005	G-2	D504	E-5
IC251	F-4	D506	F-5
IC261	D-4	D508	G-5
IC501	G-6	D509	E-6
IC502	E-5	D511	E-6
IC601	A-6	D512	E-5
IC604	A-4	D513	E-5
IC608	A-3	D514	E-5
		D515	E-5
TRANSISTOR		D601	A-8
Q001	D-2	D602	C-6
Q002	D-2	D603	A-6
Q003	D-1	D604	D-5
Q004	E-1	D605	B-6
Q005	C-1	D606	B-6
Q006	C-1	D607	B-6
Q007	F-2	D608	C-7
Q008	F-2	D609	B-6
Q009	C-3	D610	B-4
Q010	A-2	D611	D-6
Q251	E-4	D612	A-4
Q261	D-4	D613	A-5
Q271	C-5	D614	A-5
Q502	F-5	D616	D-5
Q505	E-6	D617	B-6
Q506	E-6	D618	D-5
Q507	G-5	D619	B-6
Q598	G-1	D620	D-5
Q601	B-3	D621	B-6
Q602	B-8	D622	D-5
Q603	B-4	D623	B-4
Q604	A-6	D624	B-4
Q605	D-5	D801	F-8
Q606	C-4	D802	F-10
Q607	D-5	D803	G-10
Q608	C-4	D804	E-7
Q609	C-4	D805	E-7
Q801	G-4	D806	E-9
Q804	E-10	D808	D-9
Q805	F-7		
DIODE		VARIABLE RESISTOR	
D003	A-2	RV501	F-5
D005	G-1	RV502	G-7
D006	F-1	RV601	A-7
D007	A-2		
D009	E-1	TP	
D010	G-1	TP91	G-9
D011	G-1		
D012	C-1		



1-637-020-12



TO H2 BOARD
H2-2



• D BOARD

IC001	S0A20560-A008	TUNING CTL
IC002	MC14051BCP	ON SCREEN DISPLAY
IC003	BA4558	AFT COMPARETOR
IC005	S0A2546	MEMORY
IC251	T0A2050	AUDIO OUT (L)
IC261	T0A2050	AUDIO OUT (R)
IC501	TEA2028B	DEFLECTION PROCESSOR
IC502	T0A8170	V OUT
IC601	TEA2260	PRIMARY SMPS CTL
IC604	TEA7605	+5V REG
IC608	TYA7812CT	+12V REG
Q001	0TC144EK	50/60Hz SW
Q002	0TC144EK	BLK SW
Q003	2SA1037-K	SYNC SEPARATOR
Q004	2SA1037-K	SYNC SEPARATOR
Q005	0TC144EK	Y/C SW
Q006	0TC144EK	FRONT/REAR SW
Q007	2SC2412-K	MODE 2 SWITCH
Q008	2SC2412-K	MODE 1 SWITCH
Q009	2SC2412-K	MUTE SW
Q010	2SC2412-K	RESET
Q251	2SC2412-K	AUDIO MUTE
Q261	2SC2412-K	AUDIO MUTE
Q271	2SC2412-K	VOLTAGE DETECT
Q502	2SA1037-K	CONSTANT CURRENT SOURCE
Q505	2S0774-4	V CENT
Q506	2S0743-3	V CENT
Q507	2SA1037-K	CANAL +BLK
Q598	2SA1037-K	VIDEO AMP
Q601	2SB1357T114EF	STBY SW
Q602	2S01548	REG OUT
Q603	2SB1357T114EF	STBY SW
Q604	2SA1037-K	FAST ON/OFF
Q605	2SC2412-K	STBY SW
Q606	2SC2412-K	STBY SW
Q607	2S02096-EF	+12V REG
Q608	2SC2412-K	STBY SW
Q609	2S0789-3	STBY SW
Q801	2SC2412-K	ABL AMP
Q804	2S01941-06	H OUT
Q805	2SC2688	H DRIVER
0003	1SS133	HUE CTL
0005	MTZJ5.6B	PROT
0006	MTZJ33A	VC VOLTGE REGULATION
0007	MTZJ3.9B	PLOT RESET
0009	MTZJ5.6B	CLIPPING SYNC LEVEL
0010	MTZJ6.2B	PROT
0011	MTZJ6.2B	PROT
0012	1SS133	PROT
0013	MTZJ6.8C	PROT
0271	MTZJ13B	VOLTAGE DETECT
0272	1SS133	DECOUPING MUTE AUDIO
0501	1SS133	START
0504	GP080	V PULSE OUT
0506	0A204K	CURRENT (KV-C25510 ONLY)
0508	1SS133	CANAL +BLK LEVEL
0509	1SS133	V LIN
0511	GP080	PROT
0512	GP080	PROT
0513	MTZJ4.7B	PROT
0514	1SS133	PROT (KV-C29510 ONLY)
0515	1SS133	PROT (KV-C29510 ONLY)
0601	04SB60L-F	AC RECT
0602	RGP10G	REF RECT
0603	GP080	SMPS DRIVE 1
0604	GP080	SMPS DRIVE 2
0605	GP080	SMPS DRIVE 3
0606	RGP10G	+12V RECT
0607	RGP10G	REF RECT
0608	ERC25-06S	PLUSE CLIPPER
0609	MTZJ33A	FAST ON/OFF-1
0610	CTU-12S	+14V RECT
0611	ER029-08J	+135V RECT
0612	CTU-12S	+7V RECT
0613	RGP15J	AF V RECT-1
0614	RGP15J	AF V RECT-2
0616	MTZJ6.2B	+12V REF
0617	1SS133	PRIT
0618	MTZJ5.6B	+12V REF
0619	MTZJ33A	FAST ON/OFF-2
0620	0A204K	+12V REF
0621	MTZJ33A	FAST ON/OFF-3
0622	1SS133	PROT
0623	1SS133	DECOUPING STBY
0624	1SS133	DECOUPING STBY
0630	MTZJ15A	+12V REF
0801	RGP10G	+27V RECT
0802	RGP10G	+200V RECT
0803	RGP02-17	G2 RECT
0804	GP080	H CENTER-1
0805	GP080	H CENTER-2
0806	ERC06-1SS	H DAMPER-1
0807	ERC06-1SS	H DAMPER-2
0808	ER029-08J	PIN DAMPER

• WAVEFORMS D BOARD

① 1.2Vp-p (H)	② 4.0Vp-p (V)	③ 4.8Vp-p (V)
④ 4.0Vp-p (V)	⑤ 4.0Vp-p (H)	⑥ 11.0Vp-p (H)
⑦ 14.0Vp-p (H)	⑧ 3.6Vp-p (H)	⑨ 0.1Vp-p (503KHz)
⑩ 1.4Vp-p (H)	⑪ 0.7Vp-p (V)	⑫ 2.2Vp-p (V)
⑬ 29.0Vp-p (V)	⑭ 48.0Vp-p (V)	⑮ 3.2Vp-p (H)
⑯ 250Vp-p (H)	⑰ 16.0Vp-p (H)	⑱ 900Vp-p (H)
⑲ 180Vp-p (H)	⑳ 7.0Vp-p (V)	㉑ 48.0Vp-p (V)
㉒ 1.4Vp-p (H)	㉓ 2.8Vp-p (12MHz)	


• D BOARD

* MARK

KV-C25510	KV-C29510
C519 0.47	C519 0.33
C815 1	C815 0.82
C817 0.015	C817 0.017
C821 680p 2kV	C821 470p 2kV
0506 0A204K	0506
0514 JW	0514 1SS133
0515	0515 1SS133
0-88	0-88 3P
JW202	JW202 X
JW203 X	JW203
JW204 X	JW204
JW205	JW205 X
JW206 X	JW206
JW207 X	JW207
JW216 X	JW216
JW229 X	JW229
L801	L801 3.9mH
R525 1k	R525
R561	R561 270k
R570	R570 680
R607 4.7k	R607 5.6k
R812 68k	R812 51k
R5503 4.7	R5503 10
R5506	R5506 12K

— NOT MOUNTED
X TO BE MOUNTED


A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P




• C BOARD

Q702	JC501	R OUT
Q703	BF871	R OUT
Q704	2SA10910	ACO MEASURING
Q705	JC501	G DRIVE
Q706	BF871	G OUT
Q707	2SA10910	ACO MEASURING
Q708	JC501	B DRIVE
Q709	BF871	B OUT
Q710	2SA10910	ACO MEASURING
D701	MTZJ9.1C	PROTECT
D702	ISS133	PROTECT
D703	ISS133	PROTECT
D704	ISS133	PROTECT
D705	ISS133	PROTECT
D706	ISS133	PROTECT
D707	ISS133	PROTECT
D708	ISS133	PROTECT
D709	ISS133	PROTECT
D710	ISS133	PROTECT
D711	RGP10G	HEATING VOLTAGE REC
D713	ISS133	PROTECT

• WAVEFORMS C BOARD



• C BOARD
* HAR
KV-C
C-71
R737




• V BOARD

IC1	S0A20162-A002	MICRO-CONT
IC2	SAA5246E	IVT
IC3	FCB61C65-70P	STATIC-RAM
Q1	0TCT114EK	STAND BY
Q2	2S02096	SV REG
Q3	2SC2412K	SYNC BUFFER
Q4	2SC2712K	BLK OUT
Q5	MMST2907A	B OUT
Q6	MMST2907A	G OUT
Q7	MMST2907A	R OUT
Q8	2SC2412K	PON SW
D1	MA3056M	SV REG
D3	0AP202K	PROTECT
D4	0AN202K	PROTECT
D5	0AP202K	PROTECT
D6	0AN202K	PROTECT
D7	MA3036H	PROTECT
D9	MA3068M	PROTECT

• C BOARD

Q702	JC501	R DRIVE
Q703	BF871	R OUT
Q704	2SA10910	ACO MEASURING
Q705	JC501	G DRIVE
Q706	BF871	G OUT
Q707	2SA10910	ACO MEASURING
Q708	JC501	B DRIVE
Q709	BF871	B OUT
Q710	2SA10910	ACO MEASURING
Ø701	MTZJ9.1C	PROTECT
Ø702	ISS133	PROTECT
Ø703	ISS133	PROTECT
Ø704	ISS133	PROTECT
Ø705	ISS133	PROTECT
Ø706	ISS133	PROTECT
Ø707	ISS133	PROTECT
Ø708	ISS133	PROTECT
Ø709	ISS133	PROTECT
Ø710	ISS133	PROTECT
Ø711	RGP10G	HEATING VOLTAGE REC
Ø713	ISS133	PROTECT



• WAVEFORMS * C BOARD



• C BOARD

* MARK

KV-C2551Ø	KV-C2951Ø
C-71 2P	C-71 3P
R737 820k	R737 470k



C

[R. G. B OUT]


V

[TEXT]

IFG

[SIF]


-C Board-




Note :

- : Pattern from the side which enables seeing.
- : Pattern of the rear side.

-V Board-




-IFG5.5S Board-


**IFG**

(SIF)


BA4558
RC4558P
SDA2546
TBA129
TEA2014A
TEA2031A




CXA1114P
SDA20162-A002
TDA4580-V6
TDA6200
TEA2028B




CXD1175AM




CXD2011Q



CXK-1202Q




CX20061




FCB61C65-70P
SDA20560-A006




HCF4052BM




MB40968PF




MC14053BCP
PCF8574
TC4051BPHB
TDA4660T
TDA8442-N3
TEA2260




TDA2595/V6




TDA6600-2




SAA5246PE




SBX1610-11




TDA2050



TDA4650WP




TDA8170



TEA7605
TYA7812CT
μPC24M05HF




BF871



BU508AS1H
2SD1548-LB



DTA144EK
DTC114EK
DTC124EK
DTC144EK
2SA1162G
2SB1295-UL6
2SC2412K-R



DTC144ES



2SA1091-0



2SA1220A-P
2SC2688-LK



2SB734-34
2SD774-34



2SC2785-HFE



2SD789-34




2SD2096-EF




CTU-12S



DAN202K
DAN212K
MA152WK




DAP202K
EGP20G



D4SB60L-F




ERC06-15S
RU-3AM




ERD29-08J




IMN10




MTZJ-13B
MTZJ-15A
MTZJ-3.9B
MTZJ-33A
MTZJ-36D
MTZJ-6.2B
MTZN-10C
RD5.6ESB2
RD6.8ESB2
RD9.1ESB3
UZ-4.7BSC
1SS119




RD11M-B2
RD3.6M-B2
RD5.6M-B2
RD6.8M-B2




RGP02-17




U05G



1SS226




LD-201VR



6-1. CHASSIS (KV-C2553E ONLY)


● : BVTP 3×12 7-685-648-79

■ : BVTP 4×16 7-685-663-79



6-2. PICTURE TUBE (KV-C2553E ONLY)


● : BVTP 3×12 7-685-648-79



6-3. CHASSIS (KV-C2953E ONLY)

● : BVTP 3×12 7-685-648-79

■ : BVTP 4×16 7-685-663-79



6-4. PICTURE TUBE (KV-C2953E ONLY)

